

Gniazda HPZ

STRONA MASZYNY, Z ZAWOREM

P (bar)	L	l ₂	d ₆	d ₂	d ₁ /d ₄	Nr. Części
10	21,5	13,5	10	3,5	5	HPZ80-5
	31	22	17	6	9	HPZ80-9
15	37	25	22	9	13	HPZ80-13
20	58	32	31	13	19	HPZ80-19

P (bar)	L	l ₂	d ₆	d ₂	d ₁ /d ₄	Nr. Części
10	29,5	13,5	10	3,5	5	HPZ80-5-90
	41	24	17	6	9	HPZ80-9-90
15	51	28	22	9	13	HPZ80-13-90
20	78	34	31	13	19	HPZ80-19-90

P (bar)	L	l ₂	d ₆	d ₂	d ₁ /d ₄	Nr. Części
10	29,5	13,5	10	3,5	5	HPZ80-5-45
	41	28	17	6	9	HPZ80-9-45
15	51		22	9	13	HPZ80-13-45
20	78	34	31	13	19	HPZ80-19-45

HP SYSTEMS POLSKA SP. Z O.O.

Ul. J. Styki 18/10, 03-928 Warszawa Tel.: 022 215 88 77 Fax: 022 498 64 65 Email: hps@hps-polska.pl

www.hps-polska.pl

Wtyki HPZ

STRONA FORMY

Coated with sealing compound						
L	l ₁	SW	d ₂	d ₄	d ₇	Nr. Części
18	5	7	2,7	5	M5x0,5	HPZ81-5-5x0,5
20	7	9			M8x0,75	HPZ81-5-8x0,75
24		11	4,5	M8x0,75	HPZ81-9-8x0,75	
				M10x1	HPZ81-9-10x1	
26		9	15	6	G1/8A	HPZ81-9-R1/8
	M14x1,5				HPZ81-9-14x1,5	
	G1/4A			HPZ81-9-R1/4		
	9		13	17	M14x1,5	HPZ81-13-14x1,5
					G1/4A	HPZ81-13-R1/4
					M16x1,5	HPZ81-13-16x1,5
51	16	27	13	19	M24x1,5	HPZ81-19-24x1,5
47	12	22			G1/2A	HPZ81-19-R1/2
51	16	27			G3/4A	HPZ81-19-R3/4

Coated with sealing compound							
SW	L	l ₁	l ₂	d ₂	d ₄	d ₇	Nr. Części
9	15,5	5	14,5	2,7	5	M5x0,5	HPZ81-5-5x0,5-90
	17,5	7				M8x0,75	HPZ81-5-8x0,75-90
11	27	9	23	4,5	9	M8x0,75	HPZ81-9-8x0,75-90
				6		M10x1	HPZ81-9-10x1-90
15	34	11	25	9	13	G1/8A	HPZ81-9-R1/8-90
						M14x1,5	HPZ81-13-14x1,5-90
24	47	16	42	13	19	G1/4A	HPZ81-13-R1/4-90
						M24x1,5	HPZ81-19-24x1,5-90
						G1/2A	HPZ81-19-R1/2-90

HP SYSTEMS POLSKA SP. Z O.O.

Ul. J. Styki 18/10, 03-928 Warszawa Tel.: 022 215 88 77 Fax: 022 498 64 65 Email: hps@hps-polska.pl

www.hps-polska.pl

P(Bar)	SW	l ₁	L	d ₂	d ₄	d ₇	Nr. Części
10	9	5	28	2,7	5	M5x0,5	HPZ811-5-5x0,5
		7	30			M8x0,75	HPZ811-5-8x0,75
	15	12	29	6	9	M14x1,5	HPZ811-9-14x1,5
					G1/4A	HPZ811-9-R1/4	
15	17	30	9	13	M16x1,5	HPZ811-13-16x1,5	
						G3/8A	HPZ811-13-R3/8
20	27	16	51	13	19	M24x1,5	HPZ811-19-24x1,5

HP SYSTEMS POLSKA SP. Z O.O.

Ul. J. Styki 18/10, 03-928 Warszawa Tel.: 022 215 88 77 Fax: 022 498 64 65 Email: hps@hps-polska.pl

www.hps-polska.pl